


SPINFLO LTD.


ENIGMA

OH96000

DR. REF	PART NUMBER	DESCRIPTION	QTY
1	G900	GLASS LID	1
2	PCC0681.EN	PAN SUPPORT	2
3	PCC0823	AUX BURNER CAP	1
4	PCC0822	AUX BURNER SUPPORT	1
5	MCO3065.BK	HOB TRIM L.H.	1
6	CONTACT LS	FASCIA PANEL	1
7	SEE KNOB PHOTOS	HOB CONTROL KNOB	5
8	CONTACT LS	GRILL DOOR ASSEMBLY	1
9	MCO0684	DOOR HINGE	1
10	PCO0282	SUPPORT FOR OVEN SHELF	2
11	PCC0248	SEAL, OVEN DOOR	1
PCO0250LH & PCO0251RH		NEW 2 PART DOOR SEAL	1 EACH
12	MCO0685	DOOR HINGE	1
13	PCO0454	THERMOSTAT TAP FOR OVEN	1
	PCO0474	OVEN GAS TAP/ THERMOSTAT NEW SPADE TYPE	1
14	CONTACT LS	OVEN DOOR ASSEMBLY	1
	G1000	OVEN INNER GLASS	
16	PCO0140	DOOR CATCH	1
17	PCO0295	OVEN SHELF	1
18	MCO3060.BK	TRIM, FULL FRONT	1
19	MAC0052	GRILL BURNER	1
	MAC0056	GRILL BURNER NO HOOD AFTER LATE 2006 (FRONT FLUEING)	1
	PCO0138	STUD, DOOR CATCH	1
20	PCC1420	IGNITION SWITCH PUSH	1
20	PCC1340	ROCKER IGN SWITCH	1
21	SEE KNOB PHOTOS	OVEN CONTROL KNOB	1
22	MCO3065.BK	HOB TRIM R.H.	1
23	PCC1391	SPARK GENERATOR 230V	1
24	MCP3071.BK	PRESSING HOB TOP	1
25	MCO3064.BK	HOB TRIM, REAR	1
26	PCC2005.BK	HINGE, GLASS LID	2
27	PCC0802	BURNER HEAD AND SKIRT	3
28	PCC0803	BURNER CAP	3
29	MAC0064	GRILL PAN & HANDLE	1
30	PCC1190	TRIVET	1
31	PCC1186	GRILL PAN HANDLE	1
	MAO0064	OVEN BURNER	1
	PCO0159	THERMOCOUPLE OVEN OLD STYLE	1
	PCC1121	THERMOCOUPLE OVEN NEW SPADE TYPE	1
	PCC1164	THERMOCOUPLE GRILL	1
	PCC1125	THERMOCOUPLE GRILL NEW SPADE TYPE	
	PCC0798	AUX BURNER CUP AND INJECTOR	1
	PCC0797	BURNER CUP AND INJECTOR	3
	PCC1168	HOB THERMOCOUPLE 450mm	2
	PCC1130	REAR HOB T/COUPLE NEW SPADE TYPE	2
	PCC1163	HOB THERMOCOUPLE 220mm	2
	PCC1132	FRONT HOB T/COUPLE NEW SPADE TYPE	2
	PCC0718	HOB BURNER TAP	4
	PCC0728	HOB BURNER TAP NEW SPADE TYPE	4
	PCC0719	GRILL TAP	1
	PCC0729	GRILL TAP NEW SPADE TYPE	1
	PCC1456	SPARK ELECTRODE, 1200mm HOB	2
	PCC1428	SPARK ELECTRODE, 600mm OVEN	1
	PCC1430	SPARK ELECTRODE, 600mm OVEN	1
	PCC1419	SPARK ELECTRODE, 1500mm GRILL	1
	PCC1455	SPARK ELECTRODE, 600mm HOB	1
	PCC1453	SPARK ELECTRODE, 300mm HOB	1
	PCC0500	SHUT OFF VALVE	1
	PCC0770	OVEN JET 65	1
	PCC0775	GRILL + HOB JET 62	5
	PCO0107	CAVITY CLIP (THERMOSTAT PROBE)	2

pre Jan 06
post Jan 06

***GRILL DOOR HINGES ARE PRE BONDED TO DOOR
REQUIRE WHOLE DOOR***





LE1309_SCK16XXX



		Spare part number	Spare part number	Colours available
1	Glass lid (.BK: smoked black)	SSPA0237		.BK
	Glass lid (.SBK: solid black)	SSPA0238		.SBK
2	Glass lid hinges 2x	SSPA0010		
3	Shut off assy (=incl nr 10)			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0599		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0602		
4	Pan support 2x	SSPA0970		
5	Bump stop 2x	SSPA0040		
6	Burner assy (medium)			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0118		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0119		
7	Burner assy (large)			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0123		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0126		
8	Burner assy (small)			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0104		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0106		
9	Spark electrode 4x			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0310		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0320		
10	Thermocouples hob			
	Prod date: < 31-10-2010 (10-42361460000)		For lid shut off	
	Front left	SSPA0675	SSPA0674	
	Front right	SSPA0676	SSPA0673	
	Rear Left	SSPA0675	SSPA0673	
	Rear Right	SSPA0676	SSPA0672	
	Prod date: ≥ 01-11-2010 (10-42361460001)		For lid shut off	
	Front left	SSPA0680	SSPA0689	
	Front right	SSPA0680	SSPA0689	
	Rear Left	SSPA0682	SSPA0689	
	Rear Right	SSPA0682	SSPA0689	
11	Spark ignition button incl switch	SSPA0380		
12	Light switch (not all models)	SSPA0590		
13	Gas tap burner 1x			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0432		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0430		
14	Gas tap burner (Large)			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0472		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0470		
15	Gas tap oven			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0453		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0450		
16	Gas tap grill			
	Prod date: < 31-10-2010 (10-42361460000)	N/A		
	Prod date: ≥ 01-11-2010 (10-42361460001)	SSPA0473		
17	Cut out thermal (1x NO and 1x NC)	SSPA0510		
18	Control knobs	Refer to page 4		

		Spare part number	Spare part number	Colours available
19	Grill door	Refer to page 4		
20	Oven door	Refer to page 5		
21	Glass, inner door	SSPA0256		
22	Oven door seal	SSPA0064		
23	Oven shelf x1	SSPA0984		
24	Grill pan	SSPA0994		
25	Oven burner			
	Prod date: < 31-10-2010 (10-42361460000)	SSPA0194		
	Prod date: > 01-11-2010 (10-42361460001)	SSPA0193		
26	Thermocouple oven	SSPA0632 < 31-10-2010 (10-42361460000)	SSPA0633 ≥ 01-11-2010 (≥10-42361460001)	
27	Electrode oven			
28	Oven lamp (not all models)	SSPA0562		
29	Grill Burner		SSPA0181	
30	Thermocouple grill	SSPA0181 < 25-10-2015 (< E298S.....)	SSPA0634 ≥ 26-10-15 (≥ E299S.....)	
31	Electrode grill			
32	Cooling fan kit	SSPA0526		
33	Grill shut off	SSPA0605		
34	Spark generator	SSPA0306		




Controls knobs

Control Knob sets			
			
Spare part number	SSPA0900	SSPA0904	SSPA0901
Colours available	Brushed- Nickel/Black (.BNK/BK)	Matt Nickel (.MNK) Black (.BK)	Gloss Nickel (.GNK) Matt Nickel (.MNK)
Set quantity	6	6	6

Controls knobs

Control Knob sets		
Spare part number	SSPA0905	SSPA0903
Colours available	Black (.BK)	Satin (.SA)
Set quantity	6	6

Cladding styles


No cladding	Side cladding	Behind handle cladding
		

Grill doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO4320.BKX	Clear	Black	Yes	Sides		Brushed Nickel
SMAO4320.BK1X	Clear	Black	Yes	Full		Stainless
SMAO4320.BK7X	Clear	Black	Yes	Sides		Stainless
SMAO4320.BK8X	Clear	Black	No	N/A		Brushed Nickel
SMAO4320.MIRX	Mirror	N/A	No	N/A		Stainless
SMAO4320.MIR1X	Mirror	N/A	No	N/A		Brushed Nickel


Oven door styles

Drop down oven doors



Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO4330.BKX	Clear	Black	Yes	Sides		Brushed Nickel
SMAO4330.BK1X	Clear	Black	Yes	Full		Stainless
SMAO4330.BK7X	Clear	Black	Yes	Sides and Bottom		Stainless
SMAO4330.BK8X	Clear	Black	No	N/A		Brushed Nickel
SMAO4330.MIRX	Mirror	N/A	No	N/A		Stainless
SMAO4330.MIR1X	Mirror	N/A	No	N/A		Brushed Nickel



LE1348_SOH46XXX



		Spare part number	Spare part number	Colours available
1	Glass lid (.BK: smoked black)	SSPA0239		.BK
	Glass lid (.SBK: solid black)	SSPA0240		.SBK
2	Glass lid hinges 2x	SSPA0010		
3	Shut off assy (=incl. nr 7)			
	Production date: < 25-09-2011 (< E268M....)	SSPA0599		
	Production date: ≥ 26-09-2011 (≥ E269M....)	SSPA0601		
4	Pan support 2x	SSPA0971		
5	Burner assy (medium)			
	Production date: < 25-09-2011 (< E268M....)	SSPA0113		
	Production date: ≥ 26-09-2011 (≥ E269M....)	SSPA0119		
	*SOH46000NG	Not available		
6	Burner assy (small)			
	Production date: < 25-09-2011 (< E268M....)	SSPA0107		
	Production date: ≥ 26-09-2011 (≥ E269M....)	SSPA0106		
	*SOH46000NG	Not available		
7	Thermocouples hob		For lid shut off	
	Front left	SSPA0675*	SSPA0674	
	Front right	SSPA0675*	SSPA0673	
	Rear Left	SSPA0676*	SSPA0673	
	Rear Right	SSPA0676*	SSPA0672	
	Production date: ≥ 26-09-2011 (≥ E269M.....)		For lid shut off	
	Front left	SSPA0680	SSPA0688	
	Front right	SSPA0681	SSPA0685	
	Rear Left	SSPA0681	SSPA0687	
	Rear Right	SSPA0682	SSPA0687	
	*applicable for SOH46000NG			
8	Spark electrode 4x			
	Production date: < 25-09-2011 (< E268M....)	SSPA0310		
	Production date: ≥ 26-09-2011 (≥ E269M....)	SSPA0320		
9	Bump stops 2x	SSPA0040		
10	Spark ignition button (=incl. switch)	SSPA0381		
11	Gas tap grill			
	Production date: < 25-09-2011 (< E268M....)	SSPA0472		
	Production date: ≥ 26-09-2011 (≥ E269M....)	SSPA0470		
	Production date: ≥ 15-10-2017 (≥ E288U....)	SSPA0474		
	*SOH46000NG	SSPA0472		
12	Gas tap oven			
	Production date: < 25-09-2011 (< E268M....)	SSPA0453		
	Production date: ≥ 26-09-2011 (≥ E269M....)	SSPA0450		
	Production date: ≥ 15-10-2017 (≥ E288U....)	SSPA0449		
	*SOH46000NG	SSPA0453		
13	Gas tap burner 1x			
	Production date: < 25-09-2011 (< E268M....)	SSPA0432		
	Production date: ≥ 26-09-2011 (≥ E269M....)	SSPA0430		
	Production date: ≥ 15-10-2017 (≥ E288U....)	SSPA0433		
	*SOH46000NG	SSPA0432		
14	Control knobs	Refer to page 4		
15	Grill door	Refer to page 4		

		Spare part number	Spare part number	Colours available
16	Oven door	Refer to page 4		
17	Glass, inner door	SSPA0257		
18	Oven door seal	SSPA0064		
19	Oven shelf x1	SSPA0984		
20	Bracket hinge	SSPA0013		
21	Grill pan	SSPA0992		
22	Spark generator	SSPA0306		
23	Oven burner (also applicable for SOH46000NG)	SSPA0191		
24	Thermocouple oven	SSPA0622 Prod date: < 25-09-2011 (< E268M....)	SSPA0623 Prod date: ≥ 26-09-2011 (≥ E269M....)	
25	Electrode oven			
	Thermocouple oven (*SOH46000NG)	SSPA0622		
	Electrode oven (*SOH46000NG)			
26	Grill burner			
	Production date: < 19-04-2015 (< E103S....)	Not available		
	Production date: ≥ 20-04-2015 (≥ E103S....)	SSPA0185		
27	Electrode grill	SSPA0321		
		SSPA0643 Prod date: <25-09-2011 (< E268M....)	SSPA0645 Prod date: ≥ 26-09-2011 (≥ E269M....)	
28	Thermocouple grill			
		SSPA0643 Prod date: < 19-09-2015 (< E181S....)	SSPA0644 Prod date: ≥ 20-09-2015 (≥ E182S....)	
	(*SOH46000NG)			

*SOH46000NG = Natural Gas

Control knobs

Control knob sets



Spare part number

SSPA0906

SSPA0905

SSPA0907

Colours available

Satin (.SA)

Black(.BK)

Satin(.SA)




Set quantity

6

6

6

Control knob sets



Spare part number

SSPA0904

SSPA0901

SSPA1205

Colours available

Black(.BK)

Matt Nickel(.MNK)

Chrome(.CR)




Set quantity

6

6

6

Cladding styles


No cladding	Side cladding	Behind handle cladding
		

Grill doors


Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3515.BKX	Clear	Black	No	N/A		Black
SMAO3515.BK2X	Clear	Black	Yes	Full		Black
SMAO3515.BK4X	Clear	Black	Yes	Full		Black
SMAO3515.BK5X	Clear	Black	No	N/A		Black
SMAO3515.MIRX	Mirror	Black	No	N/A		Black
SMAO3515.SLV/BKX	Clear	Black	No	N/A		Black

Oven door styles

Left hinged oven doors



Right hinged oven doors




Right hinged oven doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3535.BKRX	Clear	Black	No	N/A		Black
SMAO3535.BK2RX	Clear	Black	Yes	Full		Black
SMAO3535.BK4RX	Clear	Black	Yes	Full		Black
SMAO3535.BK5RX	Clear	Black	No	N/A		Black
SMAO3535.MIRRX	Mirror	Black	No	N/A		Black
SMAO3535.SLV/BKRX	Clear	Black	No	N/A		Black

Left hinged oven doors


Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3535.BKLX	Clear	Black	No	N/A		Black
SMAO3535.BK2LX	Clear	Black	Yes	Full		Black
SMAO3535.BK4LX	Clear	Black	Yes	Full		Black
SMAO3535.BK5LX	Clear	Black	No	N/A		Black
SMAO3535.MIRLX	Mirror	Black	No	N/A		Black
SMAO3535.SLV/BKLX	Clear	Black	No	N/A		Black






LE1317_SOH72XXX

		Spare part number	Spare part number	Colours available
1	Glass lid (BK : smoked black)	SSPA0234		.BK
	Glass lid (SBK : solid black)	SSPA0233		.SBK
2	Glass lid hinges 2x	SSPA0010		
3	Shut off assy (=incl. nr 9)	SSPA0600		
4	Pan support	SSPA0964		
5	Pan support clips 4x	SSPA0041		
	Pan support clips 50x	SSPA0042		
6	Bump stops 2x	SSPA0040		
7	Burner assy (medium)	SSPA0117		
8	Burner assy (small)	SSPA0103		
9	Thermocouples hob		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	SSPA0676	SSPA0671	
	Rear Right	SSPA0676	SSPA0670	
	Production date: ≥ 01-07-2015 (≥ E182S...)		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	SSPA0676	SSPA0671	
	Rear Right	SSPA0676	SSPA0670	
10	Spark electrode 4x	SSPA0310		
11	Gas tap oven	SSPA0452		
12	Gas tap grill	SSPA0472		
13	Spark ignition button (=incl. switch)	SSPA0381		
14	Light switch <i>*not all models</i>	SSPA0591		
15	Gas tap burner 1x	SSPA0432		
16	Control knobs	Refer to page 3		
17	Grill door	Refer to page 3		
18	Oven door	Refer to page 4		
19	Lower door <i>*only for 3/4 height</i>	Refer to page 4		
20	Glass, inner door	SSPA0253		
21	Oven door seal	SSPA0062		
22	Oven shelf	SSPA0980		
23	Grill pan	SSPA0991		
24	Oven lamp <i>*not all models</i>	SSPA0560		
25	Oven burner	SSPA0191		
26	Thermocouple oven	SSPA0642		
27	Electrode oven	SSPA0321		
28	Grill burner			
	Production date: < 13-04-2015 (< E103S....)	Not available		
	Production date: ≥ 14-04-2015 (≥ E104S....)	SSPA0185		
29	Thermocouple grill			
	Production date: < 01-07-2015 (< E182S....)	SSPA0643		
	Production date: ≥ 02-07-2015 (≥ E183S....)	SSPA0644		
30	Electrode grill	SSPA0321		
31	Spark generator	SSPA0399		

Control knobs

Control Knob sets					
	Spare part number	SSPA0901	SSPA0903	SSPA0906	SSPA0907
	Colours available	Matt Nickel (.MNK) Black (.BK) Gloss Nickel (.GNK)	Satin (.SA)	Satin (.SA)	Satin (.SA) Chrome (.CR)
	Set quantity	6	6	6	6

Cladding styles


No cladding	Side cladding	Behind handle cladding
		

Grill Doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3425.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3425.BK4X	Clear	Black	Bottom Horizontal	N/A		Stainless
SMAO3425.BK1X	Clear	Black	No	N/A		Stainless

Oven door styles


Drop down oven doors



Left hinged oven doors



Right hinged oven doors




Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3445.BKX/SVS10X	Clear	Faded dots	No	N/A		Satin
SMAO3445.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3445.BK1X	Clear	Black	No	N/A		Stainless
SMAO3445.BK2X	Clear	Black	Yes	Bottom Horizontal		Stainless
SMAO3445.BK16X	Clear	Black	No	N/A		Chrome
SMAO3445.BK3X	Clear	Black	No	N/A		Brushed nickel
SMAO3445.BK9X	Clear	Black	No	N/A		Chrome satin

Lower doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3460.SS	Clear	Black	No	N/A	N/A	N/A
SMAO3460.MIR	Clear	Mirror	No	N/A	N/A	N/A
SMAO3460.BK	Clear	Black	No	N/A	N/A	N/A






LE1362_SOH73XXX

		Spare part number	Spare part number	Colours available
1	Glass lid (Smoke black)	SSPA0234		.BK
	Glass lid (Solid black)	SSPA0233		.SBK
2	Glass lid hinges 2x	SSPA0010		
3	Shut off assy (=incl. nr 10)	SSPA0600		
4	Pan support	SSPA0969		
5	Pan support clips 4x	SSPA0041		
	Pan support clips 50x	SSPA0042		
6	Bump stops 2x	SSPA0040		
7	Hotplate 800W	SSPA0550		
	Hotplate 1000W	SSPA0551		
8	Burner assy (medium)	SSPA0117		
9	Burner assy (small)	SSPA0103		
10	Thermocouples hob		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	n.a.	n.a.	
	Rear Right	SSPA0676	SSPA0670	
	Production date: ≥ 01-07-2015 (≥ E182S...)		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	n.a.	n.a.	
	Rear Right	SSPA0676	SSPA0670	
11	Spark electrode 4x	SSPA0310		
12	Gas tap oven	SSPA0452		
13	Gas tap grill	SSPA0472		
14	Spark ignition button (=incl. switch)	SSPA0381		
15	Light switch <i>*not all models</i>	SSPA0591		
16	Gas tap burner 1x	SSPA0432		
17	Hotplate switch	SSPA0580		
18	Lamp, indicator hot plate	SSPA0561		
19	Control knobs	<i>Refer to page 3</i>		
20	Grill door	<i>Refer to page 3</i>		
21	Oven door	<i>Refer to page 4</i>		
22	Lower door <i>*only for 3/4 height</i>	<i>Refer to page 4</i>		
23	Glass, inner door	SSPA0253		
24	Oven door seal	SSPA0062		
25	Oven shelf x1	SSPA0980		
26	Grill pan	SSPA0991		
27	Oven lamp <i>*not all models</i>	SSPA0560		
28	Oven burner	SSPA0191		
29	Thermocouple oven	SSPA0642		
30	Electrode oven	SSPA0321		
31	Grill burner			
	Production date: < 13-04-2015 (>E103S....)	Not available		
	Production date: ≥ 14-04-2015 (<E104S....)	SSPA0185		

		Spare part number	Spare part number	Colours available
32	Thermocouple grill			
	Production date: < 01-07-2015 (<E182S....)	SSPA0643		
	Production date: ≥ 02-07-2015 (>E183S....)	SSPA0644		
33	Electrode grill	SSPA0321		
34	Spark generator	SSPA0399		

Control Knobs


Control Knob sets




Spare part number	SSPA0933	SSPA0901	SSPA0902
Colours available	Chrome (.CR) Capped Knobs	Gloss Nickel (.GNK) Matt Nickel (.MNK) Satin Chrome (.SCR)	Chrome (.CR) Satin (.SA)
Set quantity	6	6	6

Cladding styles


No cladding



Side cladding



Behind handle cladding




Grill Doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3425.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3425.BK4X	Clear	Black	Bottom Horizontal	N/A		Stainless
SMAO3425.BK1X	Clear	Black	No	N/A		Stainless

Oven door styles


Drop down oven doors



Left hinged oven doors



Right hinged oven doors




Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3445.BKX/SVS10X	Clear	Faded dots	No	N/A		Satin
SMAO3445.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3445.BK1X	Clear	Black	No	N/A		Stainless
SMAO3445.BK2X	Clear	Black	Yes	Bottom Horizontal		Stainless
SMAO3445.BK16X	Clear	Black	No	N/A		Chrome
SMAO3445.BK3X	Clear	Black	No	N/A		Bright nickel
SMAO3445.BK9X	Clear	Black	No	N/A		Chrome satin

Lower doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3460.SS	Clear	Black	No	N/A	N/A	N/A
SMAO3460.MIR	Clear	Mirror	No	N/A	N/A	N/A
SMAO3460.BK	Clear	Black	No	N/A	N/A	N/A






LE1363_SOH74XXX

		Spare part number	Spare part number	Colours available
1	Glass lid (Smoked black)	SSPA0234		.BK
	Glass lid (Solid black)	SSPA0233		.SBK
2	Glass lid hinges 2x	SSPA0010		
3	Pan support	SSPA0967		
4	Pan support clips 4x	SSPA0041		
	Pan support clips 50x	SSPA0042		
5	Bump stops 2x	SSPA0040		
6	Burner assy (medium)	SSPA0114		
7	Burner assy (large)	SSPA0123		
8	Spark electrode 4x	SSPA0310		
9	Thermocouples hob		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	n.a.	n.a.	
	Rear Right	SSPA0676	SSPA0670	
	Production date: ≥ 01-07-2015 (≥ E182S...)		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	n.a.	n.a.	
	Rear Right	SSPA0676	SSPA0670	
10	Gas tap oven	SSPA0452		
11	Gas tap grill	SSPA0472		
12	Spark ignition button (=incl. switch)	SSPA0381		
13	Light switch <i>*not all models</i>	SSPA0591		
14	Gas tap burner 1x	SSPA0432		
15	Control knobs	Refer to page 3		
16	Grill door	Refer to page 3		
17	Oven door	Refer to page 4		
18	Lower door <i>*only for 3/4 height</i>	Refer to page 4		
19	Glass, inner door	SSPA0253		
20	Oven door seal	SSPA0062		
21	Oven shelf	SSPA0980		
22	Grill pan	SSPA0991		
23	Oven lamp <i>*not all models</i>	SSPA0560		
24	Oven burner	SSPA0191		
25	Thermocouple oven	SSPA0642		
26	Electrode oven	SSPA0321		
27	Grill burner			
	Production date: < 13-04-2015 (<E103S....)	Not available		
	Production date: ≥ 14-04-2015 (≥E104S....)	SSPA0185		
28	Thermocouple grill			
	Production date: < 01-07-2015 (<E182S....)	SSPA0643		
	Production date: ≥ 02-07-2015 (≥E183S....)	SSPA0644		
29	Electrode grill	SSPA0321		
30	Spark generator	SSPA0399		

Control knobs

Control Knob sets		
Spare part number	SSPA0901	
Colours available	Matt Nickel (.MNK) Satin Chrome (.SCR)	
Set quantity	6	

Cladding styles


No cladding	Side cladding	Behind handle cladding
		

Grill Doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3425.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3425.BK4X	Clear	Black	Bottom Horizontal	N/A		Stainless
SMAO3425.BK1X	Clear	Black	No	N/A		Stainless

Oven door styles


Drop down oven doors



Left hinged oven doors



Right hinged oven doors




Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3445.BKX/SVS10X	Clear	Faded dots	No	N/A		Satin
SMAO3445.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3445.BK1X	Clear	Black	No	N/A		Stainless
SMAO3445.BK2X	Clear	Black	Yes	Bottom Horizontal		Stainless
SMAO3445.BK16X	Clear	Black	No	N/A		Chrome
SMAO3445.BK3X	Clear	Black	No	N/A		Brushed nickel
SMAO3445.BK9X	Clear	Black	No	N/A		Chrome satin


Lower doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3460.SS	Clear	Black	No	N/A	N/A	N/A
SMAO3460.MIR	Clear	Mirror	No	N/A	N/A	N/A
SMAO3460.BK	Clear	Black	No	N/A	N/A	N/A



CAPRICE 2020

DRAWING REF	PART NUMBER	DESCRIPTION	QTY
1	GL6060	GLASS LID 2020 BK	1
2	MCC2051	RH HINGE ASSY	1
	MCO2052	RH HINGE ARM USUALLY BONDED TO GLASS	1
3	MCC2050	LH HINGE ASSY	1
	MCO2053	LH HINGE ARM USUALLY BONDED TO GLASS	1
4	MCO2065/3.BK	TRIM HOB SUR BACK BK	1
5	PCC0628	PAN SUPPORT 2020 CHROME	1
5	PCC0628.EN	PAN SUPPORT 2020 ENAMEL	1
6	PCC0815	SCREW FOR FIXING BURNER CAP	8
7	PCC0813	BURNER CAP	4
8	MCO2065/1.BK	TRIM HOB SUR 2020 L/H BK	1
9	PCC0812	BURNER SKIRT & SPREADER	4
10	PCC0647	CLIP PAN SUPPORT PTFE TOP FIX	2
11	CONTACT LS	HOB PRESSING	1
12	PCC0814	STUD FIXED BURNER CAP	8
13	PCX0207	SCREW M4 X 90	2
14	MCO2065/2.BK	TRIM HOB SUR 2020 R/H BK	1
15	PCC0797	BURNER CUP & INJECTOR	4
19	PCC1168	THERMOCOUPLE 450MM BACK BURNER	2
20	PCC1163	THERMOCOUPLE 220MM FRONT BURNER	2
29	PCC0718	BURNER TAP FFD	4
30	PCC0719	GRILL TAP FFD	1
33	MAO0008	OVEN THERMOSTAT TAP	1
47	PCC1155	GRILL THERMOCOUPLE	1
50	MAC0052	GRILL ASSY	1
51	MCO2031	GRILLBOX LID 2020	1
52	MCO2030	GRILLBOX BODY 2020	1
54	MAO1077	ASSY PIPE & JET	1
55	PCO0158	THERMOCOUPLE 1000MM	1
56	MCO2005	BKT BURNER	1
57	PCX0164	LOCKNUT M12 BRASS	1
58	MAO0061	BURNER ASSY	1
60	MCO1186	BKT BTM REAR	1
61	PCX0184	WASHER STARLOCK 5MM	8
62	MAO0560	INNER BOX	1
64	PCO0258/1	HINGE 2 PART GUIDE PART	2
65	MCO2063.BK	TRIM SIDE CAP2020 3/4 RH BK	1
66	MCO1184	BKT BTM FRONT	1
67	MCO2064.BK	TRIM SIDE CAP2020 3/4 LH BK	1
68	PCO0282	SUPPORT OVEN SHELF	2
69	MCO0684	LH HINGE BKT LOWER DOOR	1
70	MCO2069.BK	TRIM BTM 2020 BK	1
73	MCO0685	RH HINGE BKT LOWER DOOR	1
74	PCO0649	SEAL OVEN DOOR	1
75	OH N0 REQD	LOWER DOOR ASSY PUSH CATCH	1
76	OH N0 REQD	OVEN DOOR ASSY	1
78	OH N0 REQD	GRILL DOOR ASSY	1
79	SEE KNOB PHOTOS	CONTROL KNOB BURNERS	5
	SEE KNOB PHOTOS	CONTROL KNOB OVEN	1
81	OH N0 REQD	FASCIA ASSY	1
82	PCC1420	MICRO IGNITION SWITCH	1
83	PCC1428	SPARK ELECTRODE 600MM OVEN	1
84	PCC1418	SPARK ELECTRODE 300MM GRILL	1
85	PCC1453	SPARK ELECTRODE 300MM BURNERS	2
86	PCC1455	SPARK ELECTRODE 600MM BURNERS	2
87	PCC1399	SPARK GENERATOR	1
NOT SHOWN	PCO0285	OVEN SHELF 39CM WIDE	1
NOT SHOWN	MAC0064	GRILL PAN & HANDLE	1
NOT SHOWN	PCC1190	GRILL PAN TRIVET	1
88	CONTACT LS	LOWER DOOR ASSY WITH HANDLE	1



CAPRICE 2040


89 — DOOR WITH HANDLE

CAPRICE 2040

DRAWING REF.	PART NUMBER	DESCRIPTION	QTY
1	G990.BK	GLASS LID 2040 BK	1
2	PCC2005.BK	R.H./L.H.HINGE FOR LID	2
4	MCO2065/3.BK	TRIM HOB SUR 2020 BACK BK	1
5	PCC0628	SUPPORT,PAN 2020 STYLE CHROME	1
	PCC0668	PAN SUPPORT 2040E DUAL FUEL	1
6	PCC0815	SCREW FOR FIXING BURNER CAP	8
7	PCC0813	BURNER CAP	4
8	MCO2065/1.BK	TRIM HOB SUR 2020 L/H BK	1
9	PCC0812	BURNER SKIRT AND SPREADER	4
10	PCC0647	CLIP,PAN SUPPORT PTFE TOP FIX	2
11	CONTACT LS	PRESSING TOP	1
12	PCC0814	STUD FIXED BURNER CAP	8
13	PCX0207	SCREW M4 X 90mm	2
14	MCO2065/2.BK	TRIM HOB SUR 2020 R/H BK	1
15	PCC0797	BURNER CUP AND INJECTOR	4
19	PCC1168	THERMOCOUPLE 450mm BACK BURNER	2
20	PCC1163	THERMOCOUPLE 220mm FRONT BURNER	2
29	PCC0718	BURNER TAP FFD	4
30	PCC0719	GRILL TAP, FFD	1
33	MAO0008	OVEN THERMOSTAT TAP	1
47	PCC1154	GRILL THERMOCOUPLE	1
50	MAC0052	GRILL ASSEMBLY	1
51	MCO2031	GRILLBOX, LID CAP 2020	1
52	MCO2030	GRILLBOX,BODY CAP 2020	1
54	MAO1077	ASSY,PIPE & JET CAP WORGAS BRN	1
55	PCO0158	THERMOCOUPLE 1000MM T1-22	1
56	MCO2005	BRACKET,BURNER SUPPORT WORGAS	1
57	PCX0164	LOCKNUT, M12 BRASS	1
58	MAO0064	BURNER ASSY WORGAS COMPLETE	1
60	MCO1186	BRACKET,BOTTOM REAR(CAPRICE)	1
61	PCX0184	WASHER, STARLOCK 5MM	8
62	MAO0560	INNER BOX CAP 2020 WORGAS SS	1
64	PCO0258/1	HINGE, 2 PART GUIDE PART	2
65	MCO2063.BK	TRIM,SIDE CAP2020 3/4 RH BK	1
66	MCO1184	BRACKET,BOTTOM FRNT(CAPRICE)	1
67	MCO2064.BK	TRIM,SIDE CAP2020 3/4 LH BK	1
68	PCO0282	SUPPORT,OVEN SHELF(CARA)	2
69	MCO0684	L.H. HINGE BRACKET LOWER DOOR	1
70	MCO2069.BK	TRIM,BOTTOM CAP 2020 BK	1
73	MCO0685	R.H. HINGE BRACKET LOWER DOOR	1
74	PCO0649	SEAL,OVEN DOOR CAP2020 SG01318	1
75	OH N0 REQD	LOWER DOOR ASSY PUSH CATCH	1
76	OH N0 REQD	OVEN DOOR ASSY 2020CAP	1
78	OH N0 REQD	GRILL DOOR ASSY CAP	1
79	SEE KNOB PHOTOS	CONTROL KNOB BURNERS	5
	SEE KNOB PHOTOS	CONTROL KNOB OVEN	1
81	OH N0 REQD	FASCIA ASSEMBLY	1
82	PCC1420	MICRO IGNITION SWITCH	1
83	PCC1428	SPARK ELECTRODE 600mm OVEN	1
84	PCC1418	ELECTRODE,SPARK 300mm GRILL	1
85	PCC1453	ELECTRODE,SPARK 300mm BURNERS	2
86	PCC1455	ELECTRODE SPARK, 600mm BURNERS	2
87	PCC1399	SPARK GENERATOR	1
	PCC1279	INSTRUCTIONS,USER CAP MULTI	1
	PCC0915	ELECTRIC HOTPLATE 2040E DUAL FUEL	
	PCC0614	HOTPLATE KNOB 2040E DUAL FUEL	
	PCC0948	HOTPLATE SWITCH 2040E DUAL FUEL	
	PCC0970	INDICATOR LIGHT 2040E DUAL FUEL	
NOT SHOWN	PCO0138	STUD DOOR CATCH	
NOT SHOWN	PCO0140	DOOR CATCH	
NOT SHOWN	PCO0285	SHELF,OVEN(CARA)	1
NOT SHOWN	MAC0064	GRILL PAN ASSY & HANDLE	1
NOT SHOWN	PCC1190	GRILL PAN TRIVET	1
88	CONTACT LS	LOWER DOOR ASSY WITH HANDLE	1
	PCO0535	OVEN INNER GLASS	1

CAPRICE 6000


SPINFLO
By THETFORD



CAPRICE 6000

CAPRICE 6000

DR. REF	PART NUMBER	DESCRIPTION	QTY
1	GL6010	GLASS LID	1
2	PCC0795	BURNER CUP & INJECTOR	4
4	PCC0633	PAN SUPPORT, CHROME	1
5	PCC0806	BURNER CAP	4
6	PCC0807	BURNER SKIRT	4
7	SPCC0647	CLIP FOR PAN SUPPORT	4
8	CONTACT LS	HOB PRESSING	1
9	MCO1063/3.	REAR HOB TRIM	1
10	MCO1130	GRILL BOX	1
11	MCO1144.BK	NO LONGER AVAILABLE	1
12	MCO1063/1.	L.H. SIDE TRIM, HOB	1
13	CONTACT LS	FASCIA ASSEMBLY	1
14	SEE PHOTOS	CONTROL KNOB	6
15	CONTACT LS	GRILL DOOR ASSEMBLY	1
16	CONTACT LS	OVEN DOOR ASSEMBLY	1
17	PCO0282	SHELF SUPPORT	2
18	MCO1143.BK	NO LONGER AVAILABLE	1
19	PCO0258	HINGE GUIDE, OVEN DOOR	2
20	PCO0550	INSULATION, OVEN BODY	1
21	MCO0886	REAR BOTTOM CORNER TRIM	1
22	MCO1063/2.	R.H. TRIM, HOB	1
23	PCO0553	INSULATION, OVEN BACK	1
24	MAO1135	GRILL BOX SUPPORT	2
25	MAC0052	GRILL ASSEMBLY	1
27	MCO0805	BURNER HOLDER	1
28	PCO0260	OVEN BURNER	1
29	MCO0166	OUTLET PIPE	1
30	PCO0452	OVEN THERMOSTAT	1
31	PCC0549	GRILL TAP FFD	1
32	PCC1154	GRILL THERMOCOUPLE	1
33	PCC1162	LONG THERMOCOUPLE	2
34	PCC0548	BURNER TAP FFD	4
35	PCC1157	SHORT THERMOCOUPLE	2
36	CONTACT LS	LOWER DOOR ASSEMBLY, COMPLETE	1
	PCO0245	DOOR SEAL	1
	PCC1419	GRILL ELECTRODE	1
	PCC1425	HOB ELECTRODE	4
	PCC1423	OVEN ELECTRODE	1
	PCO0158	OVEN THERMOCOUPLE	1
	PCO0235	MAGNETS, LOWER DOOR	2
	PCO0684	HINGE, LOWER DOOR R.H.	1
	PCO0685	HINGE, LOWER DOOR L.H.	1
	PCC1420	IGNITION SWITCH	1
	PCC1399	12V GENERATOR	1
	PCO0256	GRILL DOOR HINGE	2



LE1315_SOH44XXX




		Spare part number	Spare part number	Colours available
1	Glass lid (BK : smoked black)	SSPA0235		.BK
2	Glass lid hinges (2x)	SSPA0010		
3	Pan support	SSPA0961		
4	Pan support clips (4x)	SSPA0041		
	Pan support clips (50x)	SSPA0042		
5	Bump stops (2x)	SSPA0040		
6	Burner assy medium			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0114		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0812		
7	Burner assy large			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0123		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0813		
8	Spark electrode (4x)	SSPA0310		
9	Thermocouples			
	Front left			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0676		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0681		
	Front right			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0675		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0680		
	Rear right			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0676		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0682		
10	Gas tap oven			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0452		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0449		
11	Gas tap grill			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0472		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0474		
12	Spark ignition button (incl. switch)	SSPA0381		
13	Light switch <i>*not all models</i>	SSPA0591		
14	Gas tap burner (1x)			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0432		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0433 medium	SSPA0474 large	
15	Control knobs	Refer to page 3		
16	Grill door	Refer to page 3		
17	Oven door	Refer to page 4		
18	Lower door <i>*only for 3/4 height</i>	Refer to page 4		
19	Glass, inner door	SSPA0253		
20	Oven door seal	SSPA0062		
21	Oven shelf	SSPA0980		
22	Grill pan	SSPA0991		

23	Oven lamp <i>*not all models</i>	SSPA0560		
24	Oven burner			
	<i>Production date: < 31-07-21 (E212Y...)</i>	SSPA0191		
	<i>Production date: ≥ 01-08-21 (E213Y...)</i>	SSPA0198		
25	Thermocouple oven			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0642		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0623		
26	Electrode oven			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0321		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0623		
27	Grill burner			
	<i>Production date: < 13-04-2015 (<E103S....)</i>	Not available		
	<i>Production date: ≥ 14-04-2015 (≥ E104S....)</i>	SSPA0185		
28	Thermocouple grill			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0644		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0646	SSPA0636	
		<i>Including Electrode</i>	<i>Thermocouple only</i>	
29	Electrode grill			
	<i>Production Date: < 01/05/2022 (E121Z...)</i>	SSPA0321		
	<i>Production Date: ≥ 01/05/2022 (E121Z...)</i>	SSPA0646		
		<i>Including Thermocouple</i>		
30	Spark generator	SSPA0399		

Control knobs

Control Knob sets		
	SSPA0900	SSPA0901
Colours available	Brushed- Nickel/Black (.BNK/BK)	Matt Nickel (.MNK) Satin Chrome (.SCR)
Set quantity	6	6

Cladding styles


No cladding	Side cladding	Behind handle cladding
		

Grill Doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3415.BK18X	Clear	Black	No	N/A		Brushed Nickel
SMAO3415.BK15X	Clear	Black	No	N/A		Bright Nickel

Oven door styles


Drop down oven doors



Left hinged oven doors



Right hinged oven doors




Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3435.BK20X	Clear	Black	No	N/A		Brushed Nickel
SMAO3435.BK15X	Clear	Black	No	N/A		Brushed Nickel


Lower doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3450.BK	Clear	Black	No	N/A	N/A	N/A




		Spare part number	Spare part number	Colours available
1	Glass lid (.BK: smoked black)	SSPA0237		
	Glass lid (.SBK: solid black)	SSPA0238		
2	Glass lid hinges 2x	SSPA0010		
3	Shut off assy	SSPA0602		
4	Pan support (pair) (enamel)	SSPA0970		
	Pan support (pair) (Cast)	SSPA2703		
5	Bump stop (set)	SSPA0040		
6	Burner assy (Small, enamel)	SSPA0106		
	Burner assy (small, matt)	SSPA0100		
7	Burner assy (medium, enamel)	SSPA0119		
	Burner assy (medium, matt)	SSPA0132		
8	Burner assy (Large, enamel)	SSPA0126		
	Burner assy (Large, matt)	SSPA0128		
9	Spark electrode 4x	SSPA0320		
10	Thermocouples hob		For lid shut off	
	Front left	SSPA0680	SSPA0689	
	Front right	SSPA0680	SSPA0689	
	Rear Left	SSPA0682	SSPA0689	
	Rear Right	SSPA0682	SSPA0689	
11	Spark ignition button incl switch	SSPA0380		
12	Light switch (not all models)	SSPA0590		
13	Gas tap large burner	SSPA0474		
14	Gas tap burner	SSPA0433		
15	Gas tap grill	SSPA0434		
16	Gas tap oven	SSPA0449		
17	Cut out thermal (1x NO and 1x NC)	SSPA0510		
18	Control knobs	Refer to page 3		
19	Grill door	Refer to page 4		
20	Oven door	Refer to page 5		
21	Glass, inner door	SSPA0261		
22	Oven door seal	SSPA0064		
23	Oven shelf x1	SSPA0984		
24	Grill pan	SSPA0994		
25	Oven burner	SSPA0193		
26	Thermocouple oven	SSPA0633		
27	Electrode oven			
28	Oven lamp (not all models)	SSPA0562		
29	Grill Burner	SSPA0187		
30	Thermocouple grill	SSPA0647		
31	Electrode grill			
32	Cooling fan kit	SSPA0526		
33	Grill shut off	SSPA0605		
34	Spark generator	SSPA0306		

Controls knobs

Control Knob sets				
Spare part number	SSPA0900	SSPA0904	SSPA0901	SSPA0905
Colours available	Brushed-Nickel/Black (.BNK/BK)	Black (.BK)	Matt Nickel (.MKN)	Black (.BK)
Set quantity	6	6	6	6

Controls knobs


Control Knob sets		
Spare part number	SSPA0903	SSPA0931
Colours available	Satin (.SA)	Black (.BK) Brushed- Nickel (.BNK)
Set quantity	6	6

Cladding styles

No cladding



Side cladding



Behind handle cladding




Grill doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO4320.BKX	Clear	Black	Yes	Sides		Brushed Nickel
SMAO4320.BK1X	Clear	Black	Yes	Full		Stainless
SMAO4320.BK7X	Clear	Black	Yes	Sides		Stainless
SMAO4320.BK8X	Clear	Black	No	N/A		Brushed Nickel
SMAO4320.MIRX	Mirror	N/A	No	N/A		Stainless
SMAO4320.MIR1X	Mirror	N/A	No	N/A		Brushed Nickel

Oven door styles

Drop down oven doors



Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO4330.BKX	Clear	Black	Yes	Sides		Brushed Nickel
SMAO4330.BK1X	Clear	Black	Yes	Full		Stainless
SMAO4330.BK7X	Clear	Black	Yes	Sides and Bottom		Stainless
SMAO4330.BK8X	Clear	Black	No	N/A		Brushed Nickel
SMAO4330.MIRX	Mirror	N/A	No	N/A		Stainless
SMAO4330.MIR1X	Mirror	N/A	No	N/A		Brushed Nickel